

# Mixed Bed Ion Exchanger





#### The Principle

lon Exchangers are insoluble granular substances which have in their molecular structure acidic or basic radicals that can exchange. The positive or negative ions fixed on these radicals are replaced by ions of the same sign in solution in the liquid in contact with them The ion exchange is complete without deterioration or solubilization nor changing the total number of ions in the liquid before the exchange.

The ion exchange substances are used almost exclusively under the name of resins. There are two categories of it: the resins of the gel type and those of the macro porous or loosely cross-linked type. Their basic structure is identical: the macromolecular structure is obtained in both cases by copolymerization. The difference between them lies in their porosity.

- Optional adjustment for pH-value by full automatic dosing with inlet water
- Optional Process Visualisation
   Visualize and store continuously the process on the local PLC or at an upper SCADA System
- Optional Remote Access Kit for online Software updates or trouble shooting within hours

#### **Technical Data**

Capacity	1 - 150 m³/h
Inlet Pressure	0-8 bar
Temperature of Operation	1°C - 60°C
Material	1.4301 / 1.4404 Epoxy / PP
PLC	Siematic S7



## • Efficient

because of modular design and low internal water consumption

## • Full automatic

controlled by high sophisticated process measurement

#### Flexible

by using a local PLC or fully integrated in the overall process





Unsere weltweiten Partner für Vertrieb und Service Our worldwide partners for sales and service www.centec.de



Centec Germany (Hauptsitz/Headquarter) Centec Gesellschaft für Laborund Prozessmesstechnik mbH Wilhelm-Röntgen-Str. 10 D-63477 Maintal / Frankfurt Tel +49 (0) 6181 1878 0 Fax +49 (0) 6181 1878 50 info@centec.de www.centec.de

UK representative and distributor:
Protecnica Solutions Limited.
Stalworths, The Street,
Great Tey,
Colchester,
Essex, CO6 1JS,
United Kingdom

www.centec-systems.co.uk info@centec-systems.co.uk Tel: +44 (0)1206 211 921 Ext. 22

Centec Czech Republic Centec automatika spol s.r.o.

Pekarská 8 CZ-15500 Praha

Tel.: +420 257 084 111 Fax: +420 235 518 701

Centec USA Centec LLC P.O. Box 820 Germantown, WI 53022-0820

Tel.: +1-262 251-8209 Fax: +1-262 251-8376 Centec Brasil Centec América Latina Av. das Américas, 500 BI 13/313 22640-100 Rio de Janeiro, Tel./Fax: +55 21 2494 5849 Centec Serbia Centec Predstavništvo u Beogradu Bogdana Zerajica 34 11090 Belgrad, Srbija Tel./Fax: +381 11 358 11 24