



Reverse Osmosis / Nanofiltration





The Application

The Reverse Osmosis is a physical principle for the concentration of diluted materials in liquids by using pressure to reverse the natural osmosis.

The liquid which contains the material to be removed is separated by a semi permeable membrane to the liquid the concentration will be increased.

The pressure of the to be treated liquid must be high enough to stop and reverse the natural force of the osmosis process in order to pass the membrane to the liquid which contains the increasing concentration. The treated water called permeate and is practically free of all impurities, salt molecules and bacteria.

- Compact Design with low energy consumption
- Optional Process Visualisation
 Visualize and store continuously the process on the local PLC or at an upper SCADA System
- Optional Validation / Qualification for the use in pharmaceutical or Highly Purified Watertreatment Systems

Technical Data

Capacity	1 - 500 m³/h
Residual TDS	App. 1 mg/l
Inlet Pressure	0-8 bar
Operating Temperature	1-60°C
Cleaning	CIP up to 125°C
Material	1.4301 / 1.4404 / Epoxy / PP
PLC	Siematic S7
Optional	Pre-Filtration Softener Ultra Filtration Electro De-Ionisation Storage and Loop System



Hygienic

in design and fully integrated in the CIP process

Flexible

by using a local PLC or fully integrated in the overall process

Full automatic

controlled by high sophisticated process measurement

• Energy-Efficient

by using high end components





Unsere weltweiten Partner für Vertrieb und Service Our worldwide partners for sales and service www.centec.de



Centec Germany (Hauptsitz/Headquarter) Centec Gesellschaft für Laborund Prozessmesstechnik mbH Wilhelm-Röntgen-Str. 10 D-63477 Maintal / Frankfurt Tel +49 (0) 6181 1878 0 Fax +49 (0) 6181 1878 50 info@centec.de www.centec.de

UK representative and distributor:
Protecnica Solutions Limited.
Stalworths, The Street,
Great Tey,
Colchester,
Essex, CO6 1JS,
United Kingdom

www.centec-systems.co.uk info@centec-systems.co.uk Tel: +44 (0)1206 211 921 Ext. 22

Centec Czech Republic Centec automatika spol s.r.o.

Pekarská 8 CZ-15500 Praha

Tel.: +420 257 084 111 Fax: +420 235 518 701

Centec USA Centec LLC P.O. Box 820 Germantown, WI 53022-0820

Tel.: +1-262 251-8209 Fax: +1-262 251-8376 Centec Brasil Centec América Latina Av. das Américas, 500 BI 13/313 22640-100 Rio de Janeiro, Tel./Fax: +55 21 2494 5849 Centec Serbia Centec Predstavništvo u Beogradu Bogdana Zerajica 34 11090 Belgrad, Srbija Tel./Fax: +381 11 358 11 24